
Contents:

3 1/2" x 3/8" Bolts x2

3 1/4" x 3/8" Bolts x2

1/2" Chrome Spacer x2

1 1/4" Chrome Spacer x2

3/8" Locking Nut x 4

3/4" Machined Spacer x4

Compatibility:

These bags are compatible with all FXR models. Turn signals must be relocated off the strut to mount these bags. They are also compatible with hard mount backrests. These bags have been designed with a shield to protect against exhaust heat, and are compatible with most exhaust systems. Exercise caution when mounting these bags with aftermarket exhaust systems. Hot exhaust blowing directly at the fabric will melt it. Additional shielding may be necessary for some exhausts.

Instructions

Mounting the studs

DO NOT use any bolts but those supplied with this kit. Using other bolts with different head shapes may cause your bags to fall off and voids your warranty. If you are having problems mounting your bags, please contact us and we will do our best to help you.

Pre-assemble the bolts before mounting them onto the bike. On the 3 1/2" bolts, slide on a 3/4" narrow diameter machined spacer followed by a 1/2" chrome spacer. On the 3 1/4" bolts, slide on a 3/4" narrow diameter machined spacer followed by a larger diameter 1 1/4" chrome spacer. Thread a nut on to each bolt to stop them from falling apart. The nuts are crimped so you won't be able to thread them on very far.

Next, replace the bolts on your bike one at a time so the fender doesn't drop. The 3 1/4" bolts go in the front and the 2 3/4" bolts go in the rear holes of the strut. Use blue loctite on the threads when attaching the new bolts.



Correct mounting of docking points.

